


FTLFFS-0004  
FTLFFS-0005  
FTLFFS-0006  
FTLFFS-0007




**MASSAGE RECLINER SOFA**

### CONTACT US:

If you have any questions about the installation of YITAHOME products, just contact us at +1 (888) 717-8084 from Mon-Fri 8:00 AM-4:30 PM PST / Sat. 8:00 AM-12:00 PM PST or e-mail us at [after-sale.cs@hotmail.com](mailto:after-sale.cs@hotmail.com)




Alternative method to contact us (amazon.com orders only)





1. Log into your Amazon account
2. Go to "Your Orders" and find the purchase
3. Click on "Contact Seller"

- 
- 1.Two or more people are needed to complete the installation.

2.Please protect the wires and remote control accessories from damage during installation.

3.The cable tie, located beneath the chair and used to fix the motor cable, can be cut if needed.


Reference Image	Description	Qty.
	Chair base	X 1
	Backrest	X 1
	Left armrest	X 1

Reference Image	Description	Qty.
	Right armrest	X 1
	Remote control	X 1
	Power source	X 1
	Anti-fall bracket	X 2


# 1



Left armrest




Right armrest




3

# 2




Backrest





4

### 3



Anti-fall bracket X 2




5

### 4







Remote control




Power source

Connect the wire according to color – red to red, white to white. Link black wire #1 to power source, black wire #2 to remote control, and black wire #3 to black wire #4.




6

5



Installation Completed



Charge: 2.1A USB charger port that supports nearly all smart phones, iPad, and Kindle.

LIFT UP: Lifts the sofa seat.

RECLINE: Reclines the sofa seat.




POWER: Turn on/off remote control.

HEAT: Turn on/off heat function for lumbar part only.





MODE: Press to select 5 different vibration modes (pulse, press, wave, auto, normal)

Press to select which part of body the massage should focus on (back, lumbar, thighs, legs)

How to recline?




How to get footrest latch down and stand?



⚠ Please note that you need to take apart the backrest before removing the armrests.

Force apart the buckles while taking the backrest out from the armrests.



Pull out the armrests from the chair base.

